Instruction for ISO2CAR muteadaptor 86xxx





Made in Denmark by Kram Telecom A/S

Made in Denmark by Kram Telecom A/S





ISO2CAR • muteadapters

ISO2CAR • muteadapters

Product description ISO2CAR Cable 86xxx

ISO2CAR muteadaptors are used for adapting carspecific radio connectors to the Parrot carkits ISO wiring loom.

<u>Speaker-function</u>: This is achieved by using the built-in relays in the parrot mutebox, the radio sound is muted and the sound from the carkit is send trough car front speakers. This way you will achieve a perfect hand free sound without interference from the car radio.

<u>Power supply of the carkit:</u> All ISO2CAR cables are delivered with all the available power wire from the cars radio connector connected to the ISO connectors. This way you can easily supply the carkit and cutting of the cars wiring loom is minimised.

<u>Mute function</u>: The mute lead from the radio is always to be found in one of the three mute positioen of the parrot ISO connector. This way it can easily be connected to the parrot carkit. Not all radioes is equipped with this mute function.

Note 1: The ISO2CAR solutions is normaly not suiteable for systems with a seperate amplifier or active speakers.

Note 2: Some carmodels require the mutewire to be connected to the parrot carkit to enable the car speakers to be muted completely.

See our complete ISO2CAR program on www.kram.dk

Installation description ISO2CAR Cable 86xxx

1st: Remove the radio or radio unit from its position so the radio connector is visible.

2nd: Disconnect the radio connector from the radio.

3rd: Insert the ISO2CAR adaptor between radio and the radio connector on the car wiring loom.

4th: Check the configuration of the constant 12v and ignition 12v power supply wires as they in some cars can be switched. If this is the case then they can be corrected by switching the top of the Parrot fuses. **Note:** Some cars do not have an Ignition wire in the Radio connector. The ISO2CAR adaptor for these models often has a long Ignition wire to connect to a ignition wire found else were.

5th: Connect the Parrot carkits ISO connectors to the ISO connectors on the ISO2CAR adaptor.

When the Parrot carkit and the adaptor cable is installed correctly it will redirect your call through the cars front speakers.

For further information about installation of the parrot carkit please see the Parrot installation guide.

Made in Denmark by Kram Telecom A/S